

Rubber Stair Tread with DuPont[™] Kevlar®

#95 HAMMERED ONE-PIECE TREAD/RISER DESIGN PRODUCT SUBMITTAL

| Available Lengths | 36", 42", 48", 54", 60", 66", 72", 78", 84", 90", 96", 102", & 108" |
|--|--|
| Finish | Hammered |
| Nose Configuration | Square Nose |
| ASTM F2169 - Resilient Stair Treads | Type TS, Class 2, Grade 1 |
| ASTM E648 (NFPA 253) - Critical Radiant Flux | Class 1, \geq 0.45 W/cm ² |
| ASTM E662 (NFPA 258) - Smoke Density | Passes, ≤ 450 |
| CAN/ULC-S102.2 - Surface Burning | 115 Flame Spread Rating 275 Smoke Developed Classification |
| ASTM D2047 - Static Coefficient of Friction | ≥ 0.50 |
| | |

ADA Standards for Accessible Design states the floor surface shall be stable, firm and slip resistant. Our test results utilize the James Machine as described in D2047 and as described in UL410 for floor covering materials (FCM) utilizing a leather foot under dry conditions. Maintenance processes and commonly utilized site applied finishes, polishes and other sealers to maintain resilient flooring products will change the walking surface and ultimately the Static Coefficient of Friction.

ASTM F925 - Chemical Resistance

Excellent with chemicals listed in standard, Additional chemicals available via chart

ASTM F925 testing is utilized to ensure flooring materials will stand up to certain household standard chemistries. Additional chemical resistance testing performed using this test method is for informational and guidance purposes only. Proper maintenance will have an effect on chemical resistance, but the best defense against a negative effect is to clean the drop/spill from the flooring surface immediately.

| ASTM F1514 - Heat Stability | Excellent, $\Delta E \le 8$ |
|--|--|
| Sustainability Information | Made in the U.S.A. |
| | Meets Buy America Act (49 CFR Part 661) |
| | Meets Buy American Act (41 USC §§ 8301-8303) |
| | Contributes to LEED v4/4.1 |
| | FloorScore Certification |
| | Meets CA 01350 Requirements |
| | Meets CHPS Requirements |
| | NSF/ANSI 332 Platinum Certification |
| | GREENGUARD Gold Certification |
| | HPD Available |
| | Contains No Recycled Content |
| | Red List Chemical Free |
| | Recyclable through the Impact Program |
| Acclimation Time | 48 Hours |
| Service & Storage Temperature | 65° - 85° F |
| See installation document for full installation deta | ails regarding approved substrates, job site conditions and acclimation procedures |

See installation document for full installation details regarding approved substrates, job site conditions and acclimation procedures.

Product Warranty

25 Years

See product warranty for full details regarding limitations and warranty coverage.



Rubber Stair Tread with DuPont[™] Kevlar®

#95 HAMMERED ONE-PIECE TREAD/RISER DESIGN PRODUCT SUBMITTAL

| Approved Adhesives | Excelsior EN-610, Epoxy Nose Filler |
|-------------------------|--|
| | Excelsior TP-620, Pressure Sensitive Tread Tape |
| | Excelsior AW-510, Wet-Set Acrylic |
| | Excelsior C-631, Contact Adhesive |
| | Excelsior U-705, Urethane Wet-Set |
| | Excelsior EW-710, Urethane Enhanced Epoxy Adhesive |
| Technical Support | solutions@rhctechnical.com |
| Product Support | sales@roppe.com |
| Technical Documentation | www.roppe.com |

Roppe engineered Rubber Stair Treads with Kevlar® because your stairs are being put to the test every single day. From normal wear and tear to downright abuse, Roppe Rubber Stair Tread with Kevlar® will resist damage that detracts from the appearance and safety of your stairs - not just for a few years, for decades.



|--|

Butting Treads & Pattern Alignment

Wider stairwells and stairwells that require pattern alignment will require additional planning and dry fitting prior to installation. We recommend ordering treads the next size up to achieve these layouts and installations. Our treads are manufactured to be trimmed on each end of the length and the depth of the tread.

EN-610 Epoxy Nose Filler

The predominant step being used in construction today is the metal formed frame with a pan filled with concrete, having a nose radius of 1/2" maximum as spelled out in the ADA guidelines. When installing Rubber Stair Treads on these substrates, either new construction or remodel, they do not require the use of the EN-610 Epoxy Nose Filler. Fitting the tread properly to the step and creating a tight fit to the substrate will ensure proper installation and performance of the Stair Tread.

For installations that occur on other substrates (worn metal, wood, existing approved flooring types), the EN-610 Nose Filler may be required to ensure proper fit to the substrate. These substrates need to be verified for uneven wear and corrected appropriately using the best means available. One of these means is the EN-610 Epoxy Nose Filler. It is our recommendation to check for gaps between the radius in the nose of the tread and the substrate. If a gap greater than 1/4" is present, it is required to use the EN-610 Epoxy Nose Filler. If a gap of 1/2" or greater is present, the substrate should be prepared using other methods.

Of course, with any Stair Tread installation it is acceptable to utilize the EN-610 Epoxy Nose Filler.