

This document is intended to cover Care & Maintenance for all Rubber Flooring concepts for Roppe. If there are any questions or concerns, or you desire a specific maintenance instruction for a product and/or application please reach out to solutions@rhctechical.com.

- 1. RECOMMENDED CLEANERS, FINISHES, & FINISH REMOVERS 2
- 2. MAINTENANCE OVERVIEW 2
- 3. PRODUCT SPECIFIC CARE & MAINTENANCE 3
 - 3.1 ENVIRE RUBBER SHEET/TILE 3
 - 3.1.1 INITIAL MAINTENANCE 3
 - 3.1.2 DAILY MAINTENANCE 3
 - 3.1.3 ROUTINE OR PERIODIC MAINTENANCE 3
 - 3.2 RUBBER TILE, PERFORMANCE COMPOUND - OIL & GREASE RESISTANT RUBBER TILE, SPIKE/SKATE RESISTANT TILE 4
 - 3.2.1 INITIAL MAINTENANCE 4
 - 3.2.2 DAILY MAINTENANCE 4
 - 3.2.3 ROUTINE OR PERIODIC MAINTENANCE 5
 - 3.3 TUFLEX SPARTUS MULTIPURPOSE SPORTS FLOORING 5
 - 3.3.1 INITIAL MAINTENANCE 5
 - 3.3.2 DAILY MAINTENANCE 6
 - 3.3.3 ROUTINE OR PERIODIC MAINTENANCE 6
 - 3.4 RECOIL FITNESS FLOORING 6
 - 3.4.1 INITIAL MAINTENANCE 6
 - 3.4.2 DAILY MAINTENANCE 7
 - 3.4.3 ROUTINE OR PERIODIC MAINTENANCE 7
 - 3.5 ROP-CORD RECYCLED RUBBER TILE 7
 - 3.5.1 INITIAL MAINTENANCE 7
 - 3.5.2 DAILY MAINTENANCE 7
 - 3.5.3 ROUTINE OR PERIODIC MAINTENANCE 7
- 4. RESTORATION MAINTENANCE 8
- 5. OPTIONAL FLOOR FINISHES 8
 - 5.1 FINISH APPLICATION 8
 - 5.2 FINISH REMOVAL & REAPPLICATION 9
- 6. FLOORING PROTECTION 9

Prior to acceptance of this document refer to website www.roppe.com to confirm that you have the most current revision. For additional product resources, technical documents are available online at www.roppe.com. For additional technical support, send an e-mail to solutions@rhctechical.com.

1. RECOMMENDED CLEANERS, FINISHES, & FINISH REMOVERS

Excelsior NC-900 Neutral Cleaner is a pH neutral, all-purpose cleaner for the initial and daily cleaning of Resilient flooring products.

Excelsior CM-910 Cleaner/Maintainer is a pH neutral, biodegradable cleaner and maintainer for the daily cleaning or long-term preservation of rubber floor coverings. Naturally leaves a small amount of finish to protect the flooring surface from the daily activities.

Excelsior FR-920 Vinyl Flooring Finish Remover is a highly concentrated finish remover designed to remove topically applied flooring finishes from Resilient Vinyl flooring products.

Excelsior PR-930 Performance Remover is a finish remover specifically designed to remove topically applied floor finishes from resilient flooring products that are sensitive to alkalinity, such as rubber flooring and crumb/recycled rubber flooring products.

Excelsior MF-940 Matte Acrylic Floor Finish is a durable, scuff resistance acrylic floor finish, developed for Resilient flooring products.

Excelsior GF-950 Gloss Acrylic Floor Finish is a flexible, extended-wear acrylic floor finish, developed for Resilient flooring products.

Excelsior PF-960 Performance Floor Finish is a flexible floor finish specifically for use over Resilient Rubber and Rubber sports floor coverings.

Since there are many maintenance products available today for the commercial environment, we cannot test each available product for fitness of use. We have thoroughly tested these products and recommend their use. If you have a question regarding the fitness of use of other products, please contact customer service or technical services using the information below.

2. MAINTENANCE OVERVIEW

One of the greatest benefits of using Rubber Sheet/Tile flooring products is they do not require a floor finish, commonly referred to as a 'wax', within the parameters of a maintenance program.

However, these products do require daily and routine care and maintenance with cleaning equipment to maintain the desired appearance. The frequency of daily and routine maintenance will depend upon the amount and type of traffic in the area, however, maintenance may be more frequent within the first year of installation. Over time, rubber sheet/tile products will require less frequent routine maintenance due to the maturation of the product surface.

If the flooring is in an area that cannot or will not be maintained by the use of a rotary floor machine or auto scrubber, the rubber flooring must be maintained by using a site applied finish. These products will accept a finish, but once the finish is applied it will need to be maintained to ensure that finish performs as intended.

Rubber sheet/tile products generally are low maintenance products since they do not require a floor finish. With a naturally durable finish, daily and routine maintenance must be performed to maintain the appearance of the product. Low maintenance in this case is meant to be understood as "No Finish Required" which leads to removal and reapplication of the finish.

Always use untreated, new or thoroughly cleaned mops and pads when conducting daily or routine maintenance. As with any maintenance program, be sure to use proper PPE (Personal Protective Equipment) per the cleaning product SDS and ensure all maintenance procedures are conducted per the cleaning products instructions. The use of Caution Tape and/or Wet Floor Signs is recommended to prevent slips and falls.

There is a list of things that we would recommend that you not do to these flooring products as we have seen damage from these items: **DO NOT** use vacuums that have a beater bar or electric brooms with hard plastic bottoms or no padding, as this may cause discoloration, scratching and loss of sheen. **DO NOT** use highly alkaline or acidic cleaners. **DO NOT** use detergents, abrasive cleaners or "mop and shine" type products (such as Bleach, Pine-Sol, Clorox Soft Scrub, Fabuloso, Rejuvenate, Mop & Glo, Mr. Clean, Murphy's Oil Soap and similar, unapproved cleaners), as they will dull the finish and sheen of the flooring material. **DO NOT** use Mineral Spirits, Kerosene, Gasoline, Naphtha and/or other solvents to clean Luxury Vinyl Tile. **DO NOT** use sweeping compounds or cleaning agents containing oils or solvents. **DO NOT** allow excess amounts of water to sit on floor for extended periods of time.

3. PRODUCT SPECIFIC CARE & MAINTENANCE

3.1 ENVIRE RUBBER SHEET/TILE

Initial maintenance is required on Envire Rubber Sheet/Tile to prepare the material for use after the installation process. There is no "mold release" product on this material. Ensure that adhesive has cured for recommended period of time prior to conducting initial maintenance.

Depending on traffic, routine maintenance will need to be performed regularly within the first year of the installation. Within this time period, ensure daily maintenance is performed to maintain the appearance of the flooring material.

3.1.1 INITIAL MAINTENANCE

Remove any protective coverings prior to cleaning. Use dust mop and vacuum flooring to remove any dirt, dust or debris.

Mix 2-4 ounces of Excelsior NC-900 Neutral Cleaner to a gallon of clean, potable water. Use a clean mop or pump-up sprayer to apply cleaning solution to the area and let stand for 5-10 minutes. If flooring is heavily soiled, re-apply the solution and allow cleaner to remain on surface for an additional 5-10 minutes before scrubbing and removing.

If using a low-speed rotary floor machine (175 – 350 RPM), wet scrub the floor using a Mal-Grit Scrub Brush from Malish or equivalent 22 gauge soft-bristled scrubbing brush. A 3M 5100 Red Buffer Pad or equivalent may be used.

If using an auto-scrubber, wet scrub the floor using a Mal-Grit Scrub Brush from Malish or equivalent 22 gauge soft-bristled scrubbing brush. A 3M 5100 Red Buffer Pad or equivalent may be used.

Use an auto-scrubber, wet vacuum or clean mop to remove any and all excess cleaning solution. Rinse area with clean, cool water and allow floor to dry completely. Ensure flooring area is clean and that all cleaning residue has been removed (this may require additional rinsing).

Once the area is completely dry and a higher sheen is desired, use a high speed machine (1500 RPM)* to burnish the area using a 3M 4100 White Super Polish Pad or equivalent.

3.1.2 DAILY MAINTENANCE

Ensure that initial maintenance has been conducted prior to conducting daily maintenance. Use dust mop and vacuum flooring to remove any dirt, dust or debris.

Mix 2-4 ounces of Excelsior NC-900 to a gallon of clean, potable water. Use a clean mop to clean spills, dirt buildup and other debris. Rinse area with clean, cool water and allow floor to dry completely. Ensure flooring area is clean and that all cleaning residue has been removed (this may require additional rinsing) before allowing foot traffic.

3.1.3 ROUTINE OR PERIODIC MAINTENANCE

Use dust mop and vacuum flooring to remove any dirt, dust or debris.

Mix 4-6 ounces of Excelsior CM-910 to a gallon of clean, potable water. Use a clean mop or pump-up sprayer to apply cleaning solution to the area and let stand for 5-10 minutes. If flooring is heavily soiled, re-apply the solution and allow cleaner to remain on surface for an additional 5-10 minutes before scrubbing and removing.

If using a low-speed rotary floor machine (175 – 350 RPM), wet scrub the floor using a Mal-Grit Scrub Brush from Malish or equivalent 22 gauge soft-bristled scrubbing brush. A 3M 5100 Red Buffer Pad or equivalent may be used.

If using an auto-scrubber, wet scrub the floor using a Mal-Grit Scrub Brush from Malish or equivalent 22 gauge soft-bristled scrubbing brush. A 3M 5100 Red Buffer Pad or equivalent may be used.

Use an auto-scrubber, wet vacuum or clean mop to remove any and all excess cleaning solution. Rinse area with clean, cool water and allow floor to dry completely. Ensure flooring area is clean and that all cleaning residue has been removed (this may require additional rinsing).

Once area is clean and dry, dry buff area with a low-speed rotary floor machine (175 – 350 RPM) using a White Tampico Brush from Malish or equivalent polishing brush attachment. A 3M 4100 White Super Polish Pad or equivalent may be used.

3.2 RUBBER TILE, PERFORMANCE COMPOUND - OIL & GREASE RESISTANT RUBBER TILE, SPIKE/SKATE RESISTANT TILE

Initial maintenance is required on these products to prepare the material for use after the installation process. There is a residue on these products referred to as “mold release” used during manufacturing and left on to protect the flooring during installation. Ensure that adhesive has cured for recommended period of time prior to conducting initial maintenance.

Depending on traffic, routine maintenance will need to be performed regularly within the first year of the installation. Within this time period, ensure daily maintenance is performed to maintain the appearance of the flooring material.

3.2.1 INITIAL MAINTENANCE

Remove any protective coverings prior to cleaning. Use dust mop and vacuum flooring to remove any dirt, dust or debris.

Mix 2-4 ounces of Excelsior NC-900 Neutral Cleaner to a gallon of clean, potable water. Use a clean mop or pump-up sprayer to apply cleaning solution to the area and let stand for 5-10 minutes. If flooring is heavily soiled, re-apply the solution and allow cleaner to remain on surface for an additional 5-10 minutes before scrubbing and removing.

If using a low-speed rotary floor machine (175 – 350 RPM), wet scrub the floor using a Mal-Grit Scrub Brush from Malish or equivalent 22 gauge soft-bristled scrubbing brush. A 3M 5100 Red Buffer Pad or equivalent may be used but the brushes will work better for textured surfaces.

If using an auto-scrubber, wet scrub the floor using a Mal-Grit Scrub Brush from Malish or equivalent 22 gauge soft-bristled scrubbing brush. A 3M 5100 Red Buffer Pad or equivalent may be used but the brushes will work better for textured surfaces.

Use an auto-scrubber, wet vacuum or clean mop to remove any and all excess cleaning solution. Rinse area with clean, cool water and allow floor to dry completely. Ensure flooring area is clean and that all cleaning residue has been removed (this may require additional rinsing).

3.2.2 DAILY MAINTENANCE

Ensure that initial maintenance has been conducted prior to conducting daily maintenance. Use dust mop and vacuum flooring to remove any dirt, dust or debris.

Mix 2-4 ounces of Excelsior NC-900 to a gallon of clean, potable water. Use a clean mop to clean spills, dirt buildup and other debris. Rinse area with clean, cool water and allow floor to dry completely. Ensure flooring area is clean and that all cleaning residue has been removed (this may require additional rinsing) before allowing foot traffic.

3.2.3 ROUTINE OR PERIODIC MAINTENANCE

Use dust mop and vacuum flooring to remove any dirt, dust or debris.

Mix 4-6 ounces of Excelsior CM-910 to a gallon of clean, potable water. Use a clean mop or pump-up sprayer to apply cleaning solution to the area and let stand for 5-10 minutes. If flooring is heavily soiled, re-apply the solution and allow cleaner to remain on surface for an additional 5-10 minutes before scrubbing and removing.

If using a low-speed rotary floor machine (175 – 350 RPM), wet scrub the floor using a Mal-Grit Scrub Brush from Malish or equivalent 22 gauge soft-bristled scrubbing brush. A 3M 5100 Red Buffer Pad or equivalent may be used but the brushes will work better for textured surfaces.

If using an auto-scrubber, wet scrub the floor using a Mal-Grit Scrub Brush from Malish or equivalent 22 gauge soft-bristled scrubbing brush. A 3M 5100 Red Buffer Pad or equivalent may be used but the brushes will work better for textured surfaces.

Use an auto-scrubber, wet vacuum or clean mop to remove any and all excess cleaning solution. Rinse area with clean, cool water and allow floor to dry completely. Ensure flooring area is clean and that all cleaning residue has been removed (this may require additional rinsing).

Once area is clean and dry, dry buff area with a low-speed rotary floor machine (175 – 350 RPM) using a White Tampico Brush from Malish or equivalent polishing brush attachment. A 3M 4100 White Super Polish Pad or equivalent may be used but the brushes will work better for textured surfaces.

3.3 TUFLEX SPARTUS MULTIPURPOSE SPORTS FLOORING

Initial maintenance is required on Tuflex due to the residue of the manufacturing process. This residue is sanding dust on the surface and could cause a natural shading illusion at time of installation. Ensure that adhesive has cured for recommended period of time prior to conducting initial maintenance.

Depending on traffic, routine maintenance will need to be performed regularly within the first year of the installation. Within this time period, ensure daily maintenance is performed to maintain the appearance of the flooring material.

3.3.1 INITIAL MAINTENANCE

Remove any protective coverings prior to cleaning. Use dust mop and vacuum flooring to remove any dirt, dust or debris.

Mix 2-4 ounces of Excelsior NC-900 Neutral Cleaner to a gallon of clean, potable water. Use a clean mop or pump-up sprayer to apply cleaning solution to the area and let stand for 5-10 minutes. If flooring is heavily soiled, re-apply the solution and allow cleaner to remain on surface for an additional 5-10 minutes before scrubbing and removing.

If using a low-speed rotary floor machine (175 – 350 RPM), wet scrub the floor using a 3M 5300 Blue Cleaner Pad or equivalent.

If using an auto-scrubber, wet scrub the floor using a 3M 5300 Blue Cleaner Pad or equivalent.

Use an auto-scrubber, wet vacuum or clean mop to remove any and all excess cleaning solution. Rinse area with clean, cool water and allow floor to dry completely. Ensure flooring area is clean and that all cleaning residue has been removed (this may require additional rinsing).

3.3.2 DAILY MAINTENANCE

Ensure that initial maintenance has been conducted prior to conducting daily maintenance. Use dust mop and vacuum flooring to remove any dirt, dust or debris.

Mix 2-4 ounces of Excelsior NC-900 to a gallon of clean, potable water. Use a clean mop to clean spills, dirt buildup and other debris. Rinse area with clean, cool water and allow floor to dry completely. Ensure flooring area is clean and that all cleaning residue has been removed (this may require additional rinsing) before allowing foot traffic.

3.3.3 ROUTINE OR PERIODIC MAINTENANCE

Use dust mop and vacuum flooring to remove any dirt, dust or debris.

Mix 4-6 ounces of Excelsior CM-910 to a gallon of clean, potable water. Use a clean mop or pump-up sprayer to apply cleaning solution to the area and let stand for 5-10 minutes. If flooring is heavily soiled, re-apply the solution and allow cleaner to remain on surface for an additional 5-10 minutes before scrubbing and removing.

If using a low-speed rotary floor machine (175 – 350 RPM), wet scrub the floor using a Mal-Grit Scrub Brush from Malish or equivalent 22 gauge soft-bristled scrubbing brush. A 3M 5100 Red Buffer Pad or equivalent may be used but the brushes will work better for textured surfaces.

If using an auto-scrubber, wet scrub the floor using a Mal-Grit Scrub Brush from Malish or equivalent 22 gauge soft-bristled scrubbing brush. A 3M 5100 Red Buffer Pad or equivalent may be used but the brushes will work better for textured surfaces.

Use an auto-scrubber, wet vacuum or clean mop to remove any and all excess cleaning solution. Rinse area with clean, cool water and allow floor to dry completely. Ensure flooring area is clean and that all cleaning residue has been removed (this may require additional rinsing).

3.4 RECOIL FITNESS FLOORING

Initial maintenance is required on Recoil to prepare the material for use after the installation process. There is no “mold release” product on this material. Ensure that adhesive has cured for recommended period of time prior to conducting initial maintenance.

Depending on traffic, routine maintenance will need to be performed regularly within the first year of the installation. Within this time period, ensure daily maintenance is performed to maintain the appearance of the flooring material.

3.4.1 INITIAL MAINTENANCE

Remove any protective coverings prior to cleaning. Use dust mop and vacuum flooring to remove any dirt, dust or debris.

Mix 2-4 ounces of Excelsior NC-900 Neutral Cleaner to a gallon of clean, potable water. Use a clean mop or pump-up sprayer to apply cleaning solution to the area and let stand for 5-10 minutes. If flooring is heavily soiled, re-apply the solution and allow cleaner to remain on surface for an additional 5-10 minutes before scrubbing and removing.

If using a low-speed rotary floor machine (175 – 350 RPM), wet scrub the floor using a Mal-Grit Scrub Brush from Malish or equivalent 22 gauge soft-bristled scrubbing brush. A 3M 5100 Red Buffer Pad or equivalent may be used.

If using an auto-scrubber, wet scrub the floor using a Mal-Grit Scrub Brush from Malish or equivalent 22 gauge soft-bristled scrubbing brush. A 3M 5100 Red Buffer Pad or equivalent may be used.

Use an auto-scrubber, wet vacuum or clean mop to remove any and all excess cleaning solution. Rinse area with clean, cool water and allow floor to dry completely. Ensure flooring area is clean and that all cleaning residue has been removed (this may require additional rinsing).

3.4.2 DAILY MAINTENANCE

Ensure that initial maintenance has been conducted prior to conducting daily maintenance. Use dust mop and vacuum flooring to remove any dirt, dust or debris.

Mix 2-4 ounces of Excelsior NC-900 to a gallon of clean, potable water. Use a clean mop to clean spills, dirt buildup and other debris. Rinse area with clean, cool water and allow floor to dry completely. Ensure flooring area is clean and that all cleaning residue has been removed (this may require additional rinsing) before allowing foot traffic.

3.4.3 ROUTINE OR PERIODIC MAINTENANCE

Use dust mop and vacuum flooring to remove any dirt, dust or debris.

Mix 4-6 ounces of Excelsior CM-910 to a gallon of clean, potable water. Use a clean mop or pump-up sprayer to apply cleaning solution to the area and let stand for 5-10 minutes. If flooring is heavily soiled, re-apply the solution and allow cleaner to remain on surface for an additional 5-10 minutes before scrubbing and removing.

If using a low-speed rotary floor machine (175 – 350 RPM), wet scrub the floor using a Mal-Grit Scrub Brush from Malish or equivalent 22 gauge soft-bristled scrubbing brush. A 3M 5100 Red Buffer Pad or equivalent may be used.

If using an auto-scrubber, wet scrub the floor using a Mal-Grit Scrub Brush from Malish or equivalent 22 gauge soft-bristled scrubbing brush. A 3M 5100 Red Buffer Pad or equivalent may be used.

Use an auto-scrubber, wet vacuum or clean mop to remove any and all excess cleaning solution. Rinse area with clean, cool water and allow floor to dry completely. Ensure flooring area is clean and that all cleaning residue has been removed (this may require additional rinsing).

3.5 ROP-CORD RECYCLED RUBBER TILE

Initial maintenance is required to prepare the material for use after the installation process. There is no “mold release” product on this material. Ensure that adhesive has cured for recommended period of time prior to conducting initial maintenance.

3.5.1 INITIAL MAINTENANCE

Remove any protective coverings prior to cleaning. Use dust mop and vacuum flooring to remove any dirt, dust or debris.

For interior installations, use a high-CFM, high velocity vacuum to remove dust, dirt and debris that has collected on the surface.

For minor stains, mix 2-4 ounces of Excelsior NC-900 to a gallon of clean, potable water. Apply cleaning solution to the area using a pump-up sprayer and let stand for 10-15 minutes.

Using a portable box extractor or truck-mount unit with a carpet wand, hot water extract the flooring material to remove the soil. Make sure to dry stroke to leave minimal water on the flooring material.

3.5.2 DAILY MAINTENANCE

Ensure that initial maintenance has been conducted prior to conducting daily maintenance. Sweep and/or thoroughly vacuum flooring to remove any dirt, dust or debris.

3.5.3 ROUTINE OR PERIODIC MAINTENANCE

Use dust mop and vacuum flooring to remove any dirt, dust or debris.

Areas that are exposed to repeated traffic that may track in dirty rain water, dirt, debris or deicing mixtures may cause a build-up on the surface of the material.

Mix 4 ounces of Excelsior NC-900 Neutral Cleaner to a gallon of clean, potable water. Use a pump-up sprayer to apply cleaning solution to the area and let stand for 10-15 minutes.

Using a counter rotating brush machine, scrub the flooring material while wet.

Using a portable box extractor or truck-mount unit with a carpet wand, hot water extract the flooring material to remove the soil. Make sure to dry stroke to leave minimal water on the flooring material.

Depending on traffic, routine maintenance will need to be performed regularly, especially with the changing of seasons or environmental conditions.

4. RESTORATION MAINTENANCE

Mix 16 ounces of Excelsior PR-930 Performance Remover to a gallon of clean, potable water. Use a clean mop or pump-up sprayer to apply solution to the area and let stand for 5-10 minutes. Re-apply the solution and allow solution to remain on surface for an additional 5-10 minutes before scrubbing and removing.

If using a low-speed rotary floor machine (175 – 350 RPM), wet scrub the floor using a Mal-Grit Scrub Brush from Malish or equivalent 22 gauge soft-bristled scrubbing brush. A 3M 5100 Red Buffer Pad or equivalent may be used but the brushes will work better for textured surfaces.

If using an auto-scrubber, wet scrub the floor using a Mal-Grit Scrub Brush from Malish or equivalent 22 gauge soft-bristled scrubbing brush. A 3M 5100 Red Buffer Pad or equivalent may be used but the brushes will work better for textured surfaces.

Use an auto-scrubber, wet vacuum or clean mop to remove any and all excess cleaning solution. Rinse area with clean, cool water and allow floor to dry completely. Ensure flooring area is clean and that all cleaning residue has been removed (this may require additional rinsing).

Restoration Maintenance is not an exact science and may take more than one attempt. For further information please us at solutions@rhctechical.com.

5. OPTIONAL FLOOR FINISHES

Rubber Tile, Maxime and Maxime Plus do not require a finish. However, it is recommended if areas will not be maintained regularly with either a Rotary Floor Machine or Auto-Scrubber to provide an easier to maintain area.

5.1 FINISH APPLICATION

If finish must be applied, ensure that initial maintenance has been conducted prior to applying floor finish. Flooring area must be free of dust, dirt, debris, adhesive or cleaning residues, and any potential contaminates. Once applied the maintenance routine of this installation will require the use of a finish until the flooring product is removed.

For the Envire Rubber Sheet/Tile and Rubber Tile, the Excelsior MF-940, Excelsior GF-950, and/or the Excelsior PF-960 may be utilized per the application instructions. 3-4 coats of either finish should be applied while allowing each coat to dry completely before the next coat is applied.

On the Tuflex Spartus and Recoil Fitness Flooring, the Excelsior PF-960 may be utilized per the application instructions. 1-2 coats should be applied will allowing each coat to dry completely before the next coats is applied and it will be matte in appearance due to the surface of the product at the time of finishing. For a semi-gloss appearance, apply 1-2 additional coats. We do not recommend more than 6 coats to be applied.

After application of a finish, we would recommend the use of the Excelsior CM-910 Cleaner/Maintainer in place of the NC-900 Neutral Cleaner. This will help repair the finish with each cleaning and stretch the timeframe before needing a removal and recoat.

We do not recommend a finish be applied to the Performance Compound Oil & Grease Resistant, Spike/Skate Resistant Tile or the Rop-Cord Recycled Rubber Tile.

5.2 FINISH REMOVAL & REAPPLICATION

If a floor finish is applied, it will need to be regularly removed and reapplied, depending on traffic. The extent of removal will depend on the condition of the finish and if daily maintenance has been performed to protect the finish.

For removal of a light coat of finish or preparation for a recoat, mix 16 ounces of Excelsior PR-930 to a gallon of clean, potable water.

For removal of single application of finish (3-5 coats), mix 32 ounces of Excelsior PR-930 to a gallon of clean, potable water.

For removal of multiple applications of finish, mix 64 ounces of Excelsior PR-930 to a gallon of clean, potable water.

Use dust mop and vacuum to remove any dirt, dust or debris from flooring.

Using a new or thoroughly cleaned mop, apply the finish remover solution to the flooring material and allow it to stand on the surface for 10 - 20 minutes. Do not allow solution to dry.

If using a low-speed rotary floor machine (175 – 350 RPM), wet scrub the floor using a 3M 5300 Blue Cleaner Pad or equivalent.

If using an auto-scrubber, wet scrub the floor using a 3M 5300 Blue Cleaner Pad or equivalent.

Use an auto-scrubber, wet vacuum or clean mop to remove any and all excess cleaning solution. Rinse area with clean, cool water and allow floor to dry completely. Ensure flooring area is clean and that all cleaning residue has been removed (this may require additional rinsing).

For the Envire Rubber Sheet/Tile and Rubber Tile, the Excelsior MF-940, Excelsior GF-950, and/or the Excelsior PF-960 may be utilized per the application instructions. 3-4 coats of either finish should be applied while allowing each coat to dry completely before the next coat is applied.

On the Tuflex Spartus and Recoil Fitness Flooring, the Excelsior PF-960 may be utilized per the application instructions. 1-2 coats should be applied will allowing each coat to dry completely before the next coats is applied and it will be matte in appearance due to the surface of the product at the time of finishing. For a semi-gloss appearance, apply 1-2 additional coats. We do not recommend more than 6 coats to be applied.

After application of a finish, we would recommend the use of the Excelsior CM-910 Cleaner/Maintainer in place of the NC-900 Neutral Cleaner. This will help repair the finish with each cleaning and stretch the timeframe before needing a removal and recoat.

6. FLOORING PROTECTION

Do not slide or drag pallets or heavy equipment across the new flooring. When moving appliances or heavy furniture, protect flooring from scuffing and tearing using temporary floor protection.

All furniture, fixtures, and/or moving equipment casters must be made of a soft material and must have a contact point of at least 1" in width to limit indentation and flooring damage.

All rolling chairs or seating must have a resilient flooring chair pad installed over the finished floor to protect floor covering.

All fixed furniture legs must have permanent felt or soft rubber floor protectors installed on all contact points and to reduce indentation. Floor protectors must have a flat contact point of at least 1 sq. in. or 1 in. diameter and must cover the entire bottom surface of the furniture leg.

Ensure all furniture castors and chair legs are clean and free of any and all dirt and debris. Routinely clean chair castors and furniture legs to ensure that dirt or debris has not built up or become embedded in castors or floor protectors.

Replace chair castors and floor protectors at regular intervals, especially if they become damaged or heavily soiled.

Place walk-off mats at outside entrances. Ensure mats are manufactured with non-staining backs to prevent discoloration.